


FSQ-106EDX4

Photo/Visual System Chart

- 6A. C. A. A (CCA-250) [TKP86200]
- 8A. Coupling (TW) (CCA-250) [TKP86003]
- 8L. Coupling (TW) (FSQ-130ED) [TKP38003]
- 12A. Visual Adapter (CCA-250) [TKP86005]
- 13. 50.8 Sleeve [TKP00113]
- 14. Coupling (S) [TKP00103]
- 18C. Reducer CR 0.73x [TKA82580]
- 18M. 35 ReducerQE 0.6x(TBD)
- 18L. 645 ReducerQE 0.72x [TKA36580L]



- 27. 4-turret 31.7D [TKA00404]
- 30R. CA-35 (SKY90) [TKA35201]
- 32. T-mount
- 33. Wide T-mount
- 34. DSLR
- 36. TGA-4 [TKA00210]
- 46. Eyepiece adapter (31.7mm) [TKP00101]
- 47. Eyepiece (31.7mm)
- 48. Eyepiece (50.8mm)
- 49. Diagonal prism 31.7MC [TKA00547]
- 60. Extender QE 1.6x (50.8) [TKA36595]
- 70S. Extension tube (S) [TKP27110S]
- 71L. Extension tube (L) [TKP31112]
- 71S. Extension tube (S) [TKA00105]
- 74. Diagonal mirror (50.8) [TKA00543]
- 75. Adapter (DM) 31.7 [TKA00111]
- 81S. Aux. ring (FSQ-130ED) [TKA38205]
- 82. 645 RD adapter [TKA36581]